

# Automatic Control

## Experimental laboratory procedure

Automatic Control – M. Canale

## Preliminary steps

It is necessary to perform the design procedure before coming to the laboratory. The transfer function of the obtained  $C(z)$  must be saved from the MATLAB® environment on a USB drive as:

```
>> [ncd,dcd]=tfdata(Cd,'v');  
>> save Tf_ascii ncd dcd -ascii
```

The order in which variables are saved is important! Please follow this template!

The physical system will be controlled by means of a NI MyRIO® board, that implements the digital controller  $C(z)$ .

The performance of the designed control system will be evaluated by means of the following tests:


- ❖ response of the system to a **square wave**  $r_1(t)$  of peak-to-peak amplitude  $V_{pp}=0.5V$ , frequency  $f=0.1Hz$ , duty cycle  $D=50\%$ ;
- ❖ response of the system to a **sawtooth wave**  $r_2(t)$  of peak-to-peak amplitude  $V_{pp}=0.5V$ , frequency  $f=0.1Hz$ , duty cycle  $D=50\%$ .

Automatic Control – M. Canale

AC\_Lab\_lev 2

## Detailed description of the laboratory procedure

1. Login to one of the PC in the laboratory, to be able to use LabVIEW®.
2. Turn the magnetic levitator on, from the switch on the rear of the device.
3. Switch on the signal generator, and set it properly so that either  $r_1(t)$  or  $r_2(t)$  is generated.
4. Connect the MyRIO board to electricity (1), and to the PC (2).
  - a. Connect the reference  $r(t)$  (output of the signal generator) to *Analog Input 0* (3), "Position Sense" at *Analog Input 1* (4), and "Command IN" at *Analog Output 0* (5) by means of BNC cables.



Automatic Control – M. Canale


AC\_Lab\_lev 3

## Detailed description of the laboratory procedure

5. Open the LabVIEW 2016 project **RT\_Control\_Lev.proj**; therefore, open the file **RT\_Control\_lev.vi**, under the target *MyRIO-1900*.

Name

RT\_Control\_LEV.vi  
RT\_Control\_Lev.lvps  
RT\_Control\_Lev.lvproj ←  
RT\_Control\_Lev.aliaes




Automatic Control – M. Canale

AC\_Lab\_lev 4


## Detailed description of the laboratory procedure

- Start the program by clicking on the (encircled) with the arrow on the top left side.



## Detailed description of the laboratory procedure

- Upload the coefficients of C(z): insert a USB drive containing the previously generated ASCII file, in the **proper part of the MyRIO board**, type its path in (a) as "/U/Filename" and click on (b).
- Set the sampling period in (c), expressing it in  $\mu s$ .



## Detailed description of the laboratory procedure

- While keeping the mass in correspondence to the mid-point of the **position transducer** (to avoid the reaching of the saturation limit for  $u(t)$ ), switch the control loop on by clicking on **Start**. The signals can be visualised in (d).



## Detailed description of the laboratory procedure

- The data can be saved by clicking on **SAVE** (e). Saving can be interrupted by clicking again on (e). The output file is stored on the **USB drive** that was previously inserted on the board, and its name can be specified in (f) as "/U/Output\_name.lbv", and it will contain four columns: time, expressed in number of samples,  $r(t)$ ,  $y(t)$ ,  $u(t)$ .

